
E. GLAESEL.
CITHERN.

No. 582,196.


Patented May 11, 1897.





E. GLAESEL. CITHERN.

No. 582,196.

Patented May 11, 1897.







United States Patent Office.

EWALD GLAESEL, OF MARKNEUKIRCHEN, GERMANY.

CITHERN.

SPECIFICATION forming part of Letters Patent No. 582,196, dated May 11, 1897.

Application filed May 2, 1896. Serial No. 590,057. (No model.) Patented in England May 20, 1895, No. 9,963.

To all whom it may concern:

Be it known that I, EWALD GLAESEL, a subject of the King of Saxony, and a resident of Markneukirchen, in the Kingdom of Saxony, 5 Germany, have invented a certain new and useful Improved Chromatic Cithern for Melodies and Chords, (for which I have received a patent in Great Britain, dated May 20, 1895, No. 9,963,) of which the following is a full,

10 clear, and exact description.

The present invention consists of a cithern by means of which both melodies and chords may be played. In contradistinction to the citherns hitherto employed the present system 15 enables all major and minor keys and their respective chords to be played. This is accomplished by operating a slide mechanism by means of which the instrument is adjusted by a single operation to the desired key.

Citherns constructed according to the present invention may be played by persons having no knowledge of music, it only being necessary to make use of the instructions fur-

nished with the instrument.

In order to make the present invention more easily intelligible, reference is had to the accompanying drawings, in which similar letters denote similar parts throughout the several views.

30 Figure 1 is a plan view; Fig. 2, a section on the line x x of Fig. 1, and Fig. 3 a section on the line yy of Fig. 1 of an instrument constructed according to the present invention.

The cithern is tuned to the chromatic scale and includes three octaves. At the left-hand side of the instrument beneath the A string or beneath a special string s, provided for the purpose, are arranged twelve raised bars or 40 strips representing the tones of the chromatic scale.

To tune the instrument, the first octave is string and the other two octaves tuned to the 45 first.

A is a slide by means of which all the dampers may be moved simultaneously. The slide mechanism consists of a frame A between the ends c d, of which the dampers a50 are supported in angle-pieces e, said dampers being capable of being depressed and being returned to their normal position after each

depression by means of the spiral springs f, arranged under the said angle-pieces e. Above the frame is arranged a bridge or cover g, in 55 which six vertical stops h are loosely supported, each having its lower end resting on one of the dampers. A scale having Roman figures "I," "II," "III," &c., is provided in front of the stops, said numbers corresponding 60 to the position of the stops and designating the chords as prescribed by the principle of harmony. The slide is further provided with a scale having the twelve major and minor keys, the major at the left-hand side and the minor 65 at the right. The cover g is provided with arrows t t, with which the line of the key must correspond. Thus, for instance, if it is desired to play in C minor the slide must be pushed in until the line above C on the minor 70 side is in line with the two arrows of the cover g. As soon as the instrument has been adjusted to the proper scale the same may be played in the usual manner, and if a chord happens it will only be necessary to depress 75 the corresponding stop h, which by means of a felt cushion muffles or damps all the strings which are to be kept silent, allowing only the strings of the chord to speak.

I will now proceed to give a few instances 80 showing that it is possible to play in any key on the present instrument. Thus it is possible to play five different chords in every major key without shifting the slide—first, the major chord in the first position, stop I; second, the 85 major chord in the fifth position, stop V, with seventh; third, the major chord in the fourth position, stop IV; fourth, the minor chord in the sixth position, stop VI, and, fifth, the minor chord in the second position, stop II. 90 That would make, therefore, in C major, first, C, E, G; second, Bb, D, E; third, E, A, C; fourth, A, C, E; fifth, D, E, A, and with the aid of the strip III and by arranging the tuned to the marked notes of the special strips together in a suitable manner it is pos- 95 sible to use them to produce either the major or the minor key. Thus, for instance, the major chord in the third position by stop III is the same as the minor chord. For instance, supposing the instrument to be adjusted to 100 the C-major key, it would also be possible to play four chords in A minor thus: the minor chord of the first position, A, C, E; second, the minor chord from the fourth position, D, F,

A; third, the major chord of the fifth position, E, G#, B, and, fourth, the major chord in the sixth position, F, A, C. These chords would be played by depressing the stops VI, II, III, IV. The same result could be obtained, of course, in any one of the other keys.

The dampers a a consist advantageously of split brass tubes, in which a strip of felt bis clamped, as shown in Fig. 3, said strip be-10 ing cut out at such points as correspond to the positions of the strings which are to be allowed to speak when the said manual is depressed, as may be clearly seen at Fig. 2. Dampers of this construction possess the ad-15 vantage over those hitherto employed that they are elastic and will not warp, while at the same time they damp more effectually and without disturbing the harmony. The music written for eitherns of this kind is pro-20 vided at the top of each piece with a notice of the scale in which the piece is written and according to which the slide is adjusted, while above each note the number of the stop to be depressed for the corresponding chord is writ-25 ten and also the number of the strings to be struck thus:



30

The strings are all numbered at the rear of the slide from "1" to "37," comprising the

• ·

three octaves, and the number "13," "13," 35 "14," &c., above each note means that after the stop has been depressed all the strings left free by the damper from "37" to "13" are to be struck. Each number means that all strings, always counting from "37" to the 40 number, and if no number is written then all the free strings, should be struck.

Cord-citherns of the kind hitherto employed are more complicated and necessitate the adjustment of a number of stops before the 45 piece can be played, while in the present case a single movement of the slide adjusts the whole instrument and the notes show which atvince is to be stored.

string is to be struck.

I claim as my invention—

In a cithern the combination of a frame mounted to slide transversely over the strings, and a cover to the same a series of dampers mounted therein consisting of drawn-metal tubes slotted along the under side and hav-55 ing notched felt strips confined in said slot, spring-bearings to said dampers to normally keep same off the strings means to depress said dampers, a scale on said slide having major and minor keys and a suitable mark 60 on the slide-cover to enable adjustment substantially as described.

In witness whereof I have hereunto set my

hand in presence of two witnesses.

EWALD GLAESEL.

.

Witnesses:

W. BAUTZE, H. HINTZPETER.

·

•